

volkano
Stretch Series

**BLUETOOTH WIRELESS HANDSFREE
MULTIPOINT CONNECTION**


Package Contents

- Bluetooth Wireless Headset
- Charging cable (Micro-USB)
- User manual

Specifications:

Bluetooth Version: 4.1
 Bluetooth Profiles: HSF, HFP, A2DP, AVRCP
 Bluetooth Range: 10m
 Battery Capacity: 100mAh
 Playback Time: 6 hours
 Battery Type: Lithium Ion

Identifying Parts:



1. Charge port
2. Multi-function button
3. Volume +/-
4. Led indicator
5. Retract button

Charging:

You must completely charge the Volkano Stretch Headset before the first use.

Connect the USB charging cable to any powered USB port and to the Micro-USB port. Make sure it is plugged in fully. The LED light will be Red while the Headset is charging and will turn off when the Headset is ready for use.

Instructions For Use:

Turning On And Off

To turn on, press and hold the "Multi-function Button" button for approximately 3 seconds the blue LED light will start flashing. To turn off, press and hold the "Multi-function Button" button for approximately 4 seconds. The Red LED light will flash briefly.

Pairing With Bluetooth Devices

Your Headset must be paired to a Bluetooth device before it can be used. It is only necessary to pair your Headset once with each device.

1. Open the Bluetooth menu on the device you wish to pair (see "Locating the Bluetooth Menu" for more details). Some devices require you to select "Search for Devices" or "Add New Device" in order to create a Bluetooth pairing.
2. With the Headset turned off, press and hold the "Multi-function Button" button for approximately 5 seconds to enter pairing mode. The LED light will flash red and blue at a high speed while the Headset is in pairing mode.
3. Wait until you see "Stretch" on your device screen.
4. Select "Stretch" on your device and follow any further prompts to pair. Use "0000" if a pin is required. Once pairing is complete and a connection is established, the LED light will flash blue at a slower rate.

Locating The Bluetooth Menu:

iPhone, iPad, and iPod Touch

- a) On your device, go to Settings
- b) Select Bluetooth. If Bluetooth is not on, turn it on. The iPhone/iPad/iPod will automatically search for new devices

Android™ Phones and Tablets

- a) On your device, go to the Settings menu
- b) Select Bluetooth (on older Android devices Bluetooth is found in the Wireless & Networks menu). If Bluetooth is not on, turn it on. Select "Search for Devices" if your phone or tablet does not automatically search for new devices

Windows® Phone 8 Devices

- a) On your device, open the Settings menu
- b) Select Bluetooth. If Bluetooth is not on, turn it on. The Windows phone will automatically search for new devices

Connecting With Paired Devices

Once the Volkano Stretch Headset is turned on, they will automatically connect with the last paired Bluetooth device that is on and within range. If the Volkano Stretch Headset does not connect automatically, open the Bluetooth menu on your device and select "Stretch" from the Bluetooth device list.

Controls:

1. Adjusting The Volume

Function	Operation	Notes
Increase Volume	Short press the "Volume Up" button	When the volume reaches the minimum or maximum level the Volkano Stretch Headset will produce a short tone.
Decrease Volume	Short press the "Volume Down" button	

2. Controlling Phone Calls

Status	Function	Operation
Incoming Call	Answer Call	Press the "Multi-function Button" Button
	Reject Call	Press and Hold the "Multi-function Button" button for 2 seconds
Call in Progress	End Call	Press the "Multi-function Button" button

Trouble Shooting:

1. My mobile phone can't find any new Bluetooth devices?
 - a. Ensure the Device has entered the pairing mode.
 - b. Ensure the Device is within effective working range.

2. Bluetooth device can't pair up?
 - a. Ensure your mobile phone allows new connections and has not reached the maximum number of allowed devices.
 - b. Ensure the pairing password has been entered correctly "0000". If you are using a Bluetooth transmitter device, ensure the password is set to 0000.
3. The Device does not play music or answer calls when it is connected to a Bluetooth mobile phone.
 - a. Ensure your mobile phone supports A2DP and HSF (hands-free) profiles.
 - b. Ensure your mobile phone is within effective working range.
4. When paired with my computer, windows asks for a new driver. Can you supply this?

We recommend you find compatible drivers for your computer online.
5. Why can I not remotely control the pause, play, previous and next functions when music is playing?
 - a. When you are using 3.5mm AUX connection, you can't pause, change volume or skip tracks.


- b. This feature needs the Bluetooth device paired with the speaker to support AVRCP (Audio/Video Remote Control Profile). Please ensure your device supports this.

Safety Precautions:

- The product should only be used with the parts provided by the manufacturer.
- Never use your Headset near water or in areas where it can come into contact with water. Never handle the Headset if it is dropped in water or any other liquid. If the product comes into contact with water while switched off, but still plugged in, this is a safety hazard.
- Always make sure your hands are dry before touching the plug or power connections.
- Do not operate the product with a damaged cord or plug, or after it malfunctions, has been dropped, or damaged in any manner.

- The Headset is intended for personal use only. Commercial use invalidates the warranty and the supplier cannot be held responsible for injury or damage caused when using the device for any other purpose than that which it was intended for.
- This Headset is not intended for use by children, or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the device by a person responsible for their safety. Extreme caution must be exercised.
- Children should be supervised to ensure that they do not play with the Headset. Packaging must never be left within reach of children, since it is potentially dangerous.

Environmentally Friendly Disposal:



Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well being.